










*Middle Shoring Detail should be applied every 50m and also at all corner points

TYPICAL

*All anchoring depths of posts are indicative
Subcontractor to check and confirm the required anchoring depth, considering the soil conditions for the project

All dimensions are in cm



Figure 4.9 Fence and Gate details		Postcombe and Lewknor Solar Farm	
solar2		Planning	
1:100		A3	
1/1			